

Peristeen®

Coloplast

Anal plug



Coloplast A/S
Holtegård 1
3050 Humlebæk
Denmark


הוראות שימוש

23315043 Version 1

The Coloplast logo is a registered trademark of Coloplast A/S. All rights reserved. © [2013-09]

How to use Peristeen Anal Plug

The anal plug can be used by people who are faecal incontinent or suffer from involuntary passing of air (flatus). It functions as an effective barrier to faeces in the rectum.



1. Preparation

Smear a small amount of Peristeen Gel on the tip of the Peristeen Anal Plug. Other lubricants may be used instead



2. Insertion

Insert the Peristeen Anal Plug gently into the anus, just as you would a conventional suppository. Ensure that the entire Peristeen Anal Plug is inserted into the rectum, just inside the anal sphincters. Leave the gauze hanging outside of your body.



3. Use

The Peristeen Anal Plug is now correctly positioned in the rectum and will quickly expand to full size as the film dissolves in the body's natural warmth and moisture. It may be left in the rectum for up to 12 hours.



4. Removal

The Peristeen Anal Plug is removed from the rectum by gently pulling the gauze moulded into the Peristeen Anal Plug. Removing the anal plug will not activate the emptying reflex, so there is no need to hurry. A fresh Peristeen Anal Plug may be inserted immediately after removal of the old one. After use, put the Peristeen Anal Plug into a waste bin - NOT into the toilet.



Indication

The Peristeen Anal Plug is intended as a barrier to faeces in the rectum.

Contraindication

Peristeen Anal Plug must not be used, if you suffer from:

- Hemorrhoids (3rd and 4th degree)
- Anal stenosis

Information

Coloplast accepts no liability for any injury or loss that may arise if this product is used in a manner contrary to Coloplast's current recommendations.

The anal plug takes a little time to get used to if you have normal sensation in the rectal area. Often this is not the case for people who have reduced or impaired sensation.

Faeces must be firm and shaped.

The anal plug is available in two sizes. Which size to choose cannot be determined beforehand. Try both sizes and choose the one that is most effective.

Some people using the anal plug on a regular basis will find that the plug is pushed out of the rectum from time to time. There is no apparent reason for this reaction, but experience shows that the same user can resume using the plug with success after a short plug-free period.

Caution

This product should not be used without assessment by your health care professional. Contact your health care professional before you use Peristeen Anal Plug for the first time, as professional guidance in the use of the plug is vital.

The anal plug should not be used if you are suffering from diarrhoea.

If placed in the mouth, the Peristeen Anal Plug will expand and may cause choking.

Remove the anal plug when you feel the urge to defecate. If you have no sensation in the rectal area and do not feel the urge to defecate, changing plug at regular intervals is recommended.

The Peristeen Anal Plug must be removed no later than 12 hours after insertion. If you experience difficulties removing the Peristeen Anal Plug, you must contact your health care professional.

If you repeatedly experience discomfort when using the Peristeen Anal Plug, stop using it and contact your health care professional.

Keep out of reach of children.

Warning

Re-use of the single use product may create a potential harm to the user. Reprocessing, washing, disinfection, and sterilisation may compromise product characteristics, causing additional risk of physical harm to or infection of the user.

مواعي الاستخدام

إذا كنت تعاني الآتي Peristeen يجب عدم استخدام السادة الشرجية

(الواسير (الدرجة الثالثة والرابعة -

ضيق فتحة الشرج -

معلومات

أي إصابات أو تلفيات تحدث بسبب استخدام المنتج بصورة مخالفة لوصيابها Coloplast لا تتحمل شركة Coloplast

لا تستغرق السادة الشرجية إلا القليل من الوقت لتكتف مع الجسم، وذلك في حالة الإحساس الطبيعي في منطقة المستقيم.

يختلف الأمر عادةً مع الأشخاص الذين يعانون من ضيق أو خلل في الإحساس

يجب أن يكون البراز متancock القولم ومكتلًا

تتوفر السادة الشرجية بمحججين مختلفين، ولا يمكن تحديد الحجم الواجب استخدامه سلفاً. جرّب المحججين واختير الأكثر

فعالية والنسبة الكافية

قد يلاحظ بعض مستخدمي السادة الشرجية صفة منتظمة خروج السادة من المستقيم من حين لأخر. لا يوجد سبب واضح

لرد الفعل هذا، لكن التجربة أثبتت أن نفس المستخدمين يمكنهم استئناف استخدام السادة بنجاح بعد فترة وجيزة من التوقف

عن استعمالها

تنبيه

يجب عدم استعمال هذا المنتج إلا بعد التقييم بواسطة أخصائي الرعاية الصحية المتبع لاحتانك للمرة الأولى، حيث إن الإرشاد المعنوي Peristeen استشر أخصائي الرعاية الصحية قبل استعمال السادة الشرجية.

المختلف في استخدام السادة الشرجية إذا كنت تعاني الإسهال.

يُحظر استخدام السادة الشرجية إذا تم وضع السادة الشرجية

في الماء، فإنه يستدده وتسبب في الاختناق Peristeen إذا تم وضع السادة الشرجية

ازل السادة الشرجية إذا شعرت بالرغبة في التغوط، إن كنت تعاني من فقد الإحساس في منطقة المستقيم ولا تشعر بالرغبة

في غضون 12 ساعة من إدخالها. إذا واجهتك صعوبة في إزالة السادة الشرجية Peristeen يجب إزاله السادة الشرجية

فإنه يتغير عليك الاتصال بأخصائي الرعاية الصحية Peristeen.

توقف عن استخدامها، إذا واجهتك صعوبة في إزالة السادة الشرجية Peristeen.

واستشر أخصائي الرعاية الصحية

يُحظر بعيداً عن متناول الأطفال.

تحذير

إن إعادة استخدام هذا المنتج بعد الاستخدام مرة واحدة قد تؤدي إلى خطير محتمل للمستخدم، كما أن إعادة المعالجة

والتطهير والتقطيع هي عمليات قد تؤثر على خصائص المنتج، ما يؤدي وبالتالي إلى مخاطر أخرى ينجم عنها

ضرر بدني أو عدو للمستخدم

Peristeen طريقة استعمال السادة الشرجية

يمكن استخدام السادة الشرجية بواسطة المرضي الذين يعانون من التبرز الالارادي أو خروج غازات البطن بصورة لارادية. حيث تعمل السادة كهاجز منيع لوصول البراز إلى المستقيم.

الإعداد 1.

يمكن على طرف سادة الشرج Peristeen وضع كمية قليلة من الجل استخدم مواد ثالثين أخرى بدلاً منه

الدخول 2.

في فتحة الشرج برفق، تماماً كما لو كنت تقوم Peristeen أدخل السادة الشرجية في المستقيم بالكاملا، بإدخال ليونسة عادي، تأكيد من إدخال السادة الشرجية بعد تجاوز فتحة الشرج تماماً. اترك الخيط الرفيع متداخلاً خارج الجسم

الاستخدام 3.

في المستقيم بشكل صحيح، واستمدد بسرعة Peristeen تم الآن وضع السادة الشرجية إلى الحد الأقصى حيث يذوب الغشاء في الرطوبة ودرج الحرارة الطبيعية للجسم. قد تترك السادة في المستقيم لمدة تصل إلى 12 ساعة

الإزالة 4.

من المستقيم عن طريق سحب الخيط المتصصل Peristeen يتم إزاله السادة الشرجية بالسادة الشرجية، إن تؤدي إزالة السادة الشرجية إلى تنشيط الإفراخ كرد فعل عكسي، إذا فلا حاجة للإسراع إلى المرحاض، يمكن إدخال سادة شرجية جديدة فور إزالة تلك في سلة المهمات، ولا تأتي Peristeen القديمة. بعد الاستعمال، التي السادة الشرجية بها في المرحاض

Peristeen כיצד لاستعمال السادة الشرجية

ال幞ك האנאלי מתחאים לשימוש על-ידי אנשים מסוימים מבריחת צואה או מהצברות גדים בבטן (נפיהנות). הוא מתפרק כמחושים יעל מפנִי צואה בחלחולות.

הכנה 1.

על קצה幞ק האנאלי של Peristeen יש למרוח כמה טבונה של גל' Peristeen. ניתן להשתמש במקום צאת חומרו סיכה אחרים.

הזרה 2.

בעדיבות אל פי הטבעת, Peristeen יש להכניס את幞ק האנאלי מוכסם כפי שמחדרים נר גל'. יש לוזואו כי幞ק האנאלי של במלאו לחחלחולת, בטור הסוגרים האנאליים. יש להשאר את הרשת תלויה מתחן לגוף.

שימוש 3.

מציב נתת כראוי בחחלחולות, ויתרחב Peristeen幞ק האנאלי של במחיירות לאגדו המלא כשר הסרט יתמוסוו בחום והחלחות הטבעיים של הגוף. ניתן להשאר את幞ק בחחלחולות למשך 12 שעות לפחות.

הוצאה 4.

מהחלחולות על-ידי משיכה Peristeen לשחוציא את幞ק האנאלי של החזאת Peristeen. עדינה של הרשת המחווררת ל幞ק האנאלי של幞ק האנאלי לא תעורר את רולקס ההתרוקנות, קר שאין גורם למחר. לאחר החזאת幞ק Peristeen יש להחדר מיד פקק אנאלי חדש של Peristeen הישן, לאחר השימוש, של להשיר את幞ק האנאלי של אשהפה - ולא לאסלה.

